

Atlas Perfector Critical Spare Parts Lists

ATLAS PERFECTOR		Critical Spare Parts List	
Item No.	Part No.	Description	Recommended On-Hand Quantity
1	001025	Oscillator Gear Bearing	2
2	001016	Rubber Bearing	6
3	1514380	Ink Fountain Cheek Seal	2
4	1516251	M/M Link	1
5	1516570	Small M/M Link Bearing	2
6	1516580	Large M/M Link Bearing	2
7	3514270	Oscillator Drive Pin	2
8	513380	Circumferential Shoe	2
9	514310	2 3/4" Rubber Roll	1
10	514370	3" Rubber Roll	1
11	514640	2 7/8" Rubber Roll	1
12	515280	2 7/8" Rubber Roll / WTR	1
13	040052	Water Fountain Drive Motor	1
14	040055	Brush Drive Motor - Page 1	1
15	040057	Brush Drive Motor - Page 2	1
16	060001	Unit Drive Belt	1
17	060046	Water Fountain Drive Belt	1
18	068002	One Way Clutch	2
19	1524011	Ink Roller Hanger Bracket	1
20	1524021	Ink Roller Hanger Bracket	1
21	1822011	Water Roller Hanger Bracket	1
22	1822021	Water Roller Hanger Bracket	1
23	2825121	Water Roller Hanger Bracket	1
24	090062	Brush Roll Assembly	1