

## Quad-Stack Integrated Roll Unit Critical Spares

### Standard roll shaft model

QUAD STACK		Roll Under Spares	
1	11023810	Brake Pad	2
2	11025110	Roll Shaft (std.) Bushing	2

### Air shaft model

QUAD STACK		Roll Under Spares	
1	11023810	Brake Pad	2
2	11025100	Roll Shaft (air) Bushing	2