

Quad Stack Single Oscillator Critical Spares List

QUAD STACK		Critical Spare Parts List	
Item No.	Part No.	Description	Recommended on-hand Quantity
1	001132	Brush Roll Bearing	4
2	001016	ER-16C Bearing	6
3	001068	3/4" Roller Bearing	4
4	001131	Water Roll Bearing	4
5	051313	Pneumatic Valve	1
6	060077	Module To Module Drive Belt	1
7	060078	Main Drive Belt	1
8	060056	Brush Drive Belt	1
9	11000650	2 1/2" Rubber Ink Roll	1
10	11000670	2 3/8" Rubber Dampener Roll	1
11	11001900	Ink Fountain Seal	2
12	002083	*Oscillator Gear Box Slider Bearing	2
13	11006150	Roller Hanger Bracket (Lower)	1
14	11006250	Roller Hanger Bracket (Upper)	1
15	11020050	Roller Hanger Bracket Stud (Lower)	1
16	11020100	Roller Hanger Bracket Stud (Lower)	1
17	514370	3" Rubber Ink Roll	1
18	514640	2 7/8" Rubber Ink Roll	2
19	001006	Drive Shaft Bearing	2
20	001023	Idler Bearing	2
21	001074	Oscillator Gearbox Bearing	4
22	040055	Brush Motor Page 1	1
23	040057	Brush Motor Page 2	1
24	040108	Water Fountain Motor	1
25	051323	Form roll Air Cylinder	1
26	051349	Impression Air Cylinder	1
27	067079	Oscillator Worm Gear	1
28	051313	Miniature 4-way Air Valve	2
29	11001260	Ink Fountain Motor RH / LH	1
30	090007	Blanket	8
31	11003400	Oscillator Worm Gear Spacer	2
32	11003501	*Oscillator Gearbox Bearing Plate	1
33	11003601	*Oscillator Side Plate	1
34	11003650	Oscillator Gearbox Bearing Plate	1
35	11003751	*Oscillator Slide Plate Page 1	1
36	11004003	Oscillator Gear Assembly	1
37	11004050	Oscillator Horizontal Slider	1
38	11004101	*Oscillator Slide Plate Page 2	1
39	040117	Compensator Motor	1

NOTE: This list reflects the most recent manufacture of the Single Oscillator Quad-Stack.

*Items notated may have a different part number corresponding to an earlier build. Please check drawings 520108200, 520108102, and 520108202 in the online Single Oscillator parts manual pages to compare oscillator systems when deciding what to order. (ie: it may be 11003500 rather than 11003501)